


INSTALLING YOUR CONCRETE SINK USING "J1" (ADJUSTABLE) BRACKETS IN COMBINATION WITH "L" BRACKETS



APPLICATIONS

Trueform Adjustable Stud Brackets and L Brackets can be mounted to either wood studs or steel* studs.

TOOLS NEEDED

- Pencil
- Tape Measure
- Laser level
- Torpedo level
- 2 C-clamps
- Drill
- 3/16" drill bit
- 5/16" drill bit
- 1/2" socket
- 1/2" box wrench
- 9/16" socket
- Silicone

INCLUDED HARDWARE

L Bracket

5/16" x 2-1/2" hex head wood screw (4 per bracket)

Each Adjustable Stud Bracket (FSB-B1-AL or FSB-B1-AS) includes the following:

- Part B1
- Part AL or AS (depends on sink depth)
- 3/8" swivel foot (1 per bracket)
- 3/8" x 2" hex head screw (1 per bracket)
- 5/16" x 1-1/2" hex head wood screw (2 per bracket)
- 5/16"-18 x 1" bolt (2 per bracket)
- 5/16"-18 nut (2 per bracket)

MOUNTING TO WOOD STUDS

Complete mounting hardware is included for wood stud applications only.

*MOUNTING TO STEEL STUDS (MIN. 18 GA)

Although these brackets are engineered for both wood and steel studs, Trueform strongly recommends outfitting the wall with wood studs when possible. Therefore, mounting screws are **not** included for steel stud applications.

If brackets must be installed on steel studs, we recommend using 5/16" hex-head sheet metal screws. Also note that applicable steel studs should be no thinner than 18 gauge.

Step 1. Installing L Brackets

It is important to note that brackets must be mounted to wood (or steel*) studs and must be perfectly leveled, both independently and to each other. Do not measure from the floor when leveling brackets since the floor may not be level. *See previous page for details on steel studs.

- 1. Mark the stud wall where you would like the center of the sink to be.
- 2. Determine the desired finished sink height and mark the stud 1" below. For example, a finished height of 34" (ADA height) would result in a mark at 33" from the finished floor. This is your *L Bracket installation height* (*L-Height*).
- 3. Set your laser level to the **L-Height**.
- 4 Determine and mark the distance from *Center* to where the left and right brackets will be mounted. The *Bracket-to-Center* dimensions are found on your Trueform Custom Drawing. If there is no stud where the brackets will be attached, either a full stud must be added or an existing nearby stud must be packed to meet this distance. Doubling up studs is recommended for L Brackets.
- 5. Clamp the L Bracket to the first mounting stud so that the top of the horizontal arm meets the **L-Height**.
- 6. Use your torpedo level to ensure the horizontal arm is level.
- 7. When the L Bracket is level and at the appropriate height, run the 5/16" drill bit in reverse at each hole to create an index which is perfectly centered in each hole.
- 8. Create holes for the 5/16" x 2-1/2" hex head wood screws using the 3/16" drill bit.
- 9. Drive the 5/16" x 2-1/2" hex head wood screws into the stude using the 1/2" socket.
- 10. If necessary, repeat steps 4-9 for the other L Bracket. Note that if the other side of the sink touches a wall, a L Bracket may not be necessary and wall cleating may be used.

Step 2. Installing Adjustable Stud Brackets

Each Adjustable Stud Bracket has 2 parts:







B1 comes in a single size and must be installed such that brackets will be both level and spaced across the mounting wall properly. B1 can be installed with the vertical stud mounting plate oriented either upward or downward.




AL or **AS**: Supporting Arm

The arm will arrive to you in one of two lengths and is determined by the countertop depth of your sink:

AL (Long): Counter depths 20 1/2" - 24" **AS** (Short): Counter depths 17" - 20 1/2"

- 1. Make a mark 6" below your **L-Height** and move the laser level to this height. This is your *Adjustable Bracket Height* (**B1-Height**).
- 2. Mark lateral locations along the wall so that the **distance between any two brackets does not exceed 32**". You may need to add studs in these locations, however, doubling them up is not necessary. Be careful to maintain at least a 4" distance from any sink drain location.
- 3. Clamp **Part B1** to the mounting stud so that the top of the horizontal arm meets the **B1-Height** and the front face of the vertical length is flush with the front face of the stud. Note that B1 can be mounted in an "upside-down" orientation should conditions require it.
- 4. Use your torpedo level to ensure the horizontal arm is level.

- 5. Use the 5/16" and 3/16" drill bits in the same manner as the L Bracket installation steps 7 & 8.
- 6. Use the 1/2" socket to drive the 5/16" x 1-1/2" hex head wood screws into the stud.
- 7. Repeat steps 1-6 for all Parts B1. The wall can now be closed up and finished with drywall or tile.
- 8. Attach Parts AS or AL slightly less than hand-tight to Parts B1 using the 5/16"-18 nuts and bolts so you can adjust Parts AS or AL to their final locations.
- 9. Set the distance from the center of the swivel feet to the finished wall, which is determined by subtracting 1-3/4" from the overall sink deck depth.
- 10. Use the 1/2" socket and 1/2" box wrench to tighten the hardware. Due to the tolerance between the bolts and the slots, it is important to apply slight downward pressure on the swivel foot during this step. The top surfaces of Parts AS or AL and B1 should be flush.
- 11. When all brackets are complete, the swivel feet should be level with each other and approximately 1 1/4" below the finished sink height when the leveling screws are midway between the top and bottom positions with room for adjustment in both directions



L-Height for an ADA-level sink (i.e. finished height of 34") is 33" plus the thickness of the finished floor. **B1-Height** is equal to **L-Height** minus 6".

Step 3. Cleating & Setting the Sink

- 1. Cleating is optional but recommended. Once the wall has been closed-up, you may install horizontal cleating on the back wall (and side walls, if applicable) between brackets at the L-Height. Ensure the distance between any cleat and another support does not exceed 32".
- 2. When the heights and measurements of all components have been verified, apply silicone to all contact points (top of horizontal L Bracket arm, top of Adjustable Bracket swivel feet, and top of each cleat [if applicable]). The sink is now ready to be set.
- 3. When setting the sink, the L Bracket(s) will contact the underside of the 1" thick sink deck. The swivel feet will contact a built-up area underneath the front of the sink basin (either by plywood or concrete). Note that you will arrive with this surface already prepared.
- 4. Ensure that all all swivel feet are making contact with the underside of the sink, and use the 9/16" socket to adjust the swivel feet height as necessary to level the sink.

Product Care & Maintenance

The following instructions are for our indoor products sealed with our topical sealer.

Now that your concrete is installed, you'll want to properly care for it. Follow these simple guidelines to keep your concrete looking beautiful for years to come:

- Avoid dragging sharp, hard objects across the concrete surface to prevent scratching. Minor white scratches should be
 expected throughout the piece from use over time. Applying *Pledge* every now and then can fill in minor scratches and give
 your pieces a nice sheen.
- Avoid using or leaving acidic foods and beverages (lemon juice, mustard, vinegar, wine, soda, tomatoes, bananas, pumpkins/gourds, etc.) perfumes and colognes, cleaners that contain vinegar or citric acids, and other harsh chemicals or solvents (ammonia, acetone, hydrogen peroxide, etc.) on the concrete surface. Clean or remove these substances as soon as possible as they may "eat" through the sealer (which can leave a light hazing) and could possibly expose or stain your concrete. There are, of course, other items and products that may damage your sealer. We have tested against the most typical stain agents, but please use standard precautions to keep your concrete protected.
- Avoid using abrasive soaps, cleansers, or scrubbing pads that can wear down the sealer. We recommend using mild, non-abrasive, non-ammonia, non-citric acid, non-vinegar, non-bleach soaps and cleaners.
- Please use standard care and precautions with your concrete products. Concrete is extremely durable; however, it is not invincible. Excessive force can do damage to your piece.

For more information see our Product Care & Use Sheets at https://www.trueformconcrete.com/product-care-use-sheets/

Warranties, Limitations of Liability and Exclusive Remedies

TRUEFORM warrants for a period of one (1) year from the date of delivery that its Products shall perform in a good and workmanlike manner in accordance with applicable standards; comply with any applicable laws, rules or regulations; and not violate or infringe upon any presently issued patent or copyright of any third party. This warranty does not include or cover 1) hairline cracks in the concrete, 2) damage caused during installation or due to incorrect installation, 3) damage caused by incorrect cleaning or care, 4) damage caused by incorrect use, 5) damage caused by acts of abuse to the products such as scratches, chips, stains, or other markings/damage, or 6) damage caused by drilling into or attempting to alter the product from the way in which it was received.

THE FOREGOING WARRANTIES ARE TRUEFORM'S ONLY WARRANTIES CONCERNING THE PRODUCTS, AND ARE MADE FOR THE BENEFIT OF THE CUSTOMER ONLY AND ARE IN LIEU OF ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE.

TRUEFORM's sole responsibility is limited to the repair or replacement, at its own expense, of any non-conforming TRUEFORM Products discovered by the Customer and reported to TRUEFORM within seven (7) days from the date of delivery.

TRUEFORM SHALL HAVE NO LIABILITY OR OTHER RESPONSIBILITY TO THE CUSTOMER OR ANY THIRD PARTY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE ALLEGEDLY CAUSED DIRECTLY OR INDIRECTLY BY OUR PRODUCTS AND SERVICES AND THE USE OF THIS MANUAL, INCLUDING, BUT NOT LIMITED TO, ANY INTERRUPTION OF SERVICE, LOSS OF BUSINESS, ANTICIPATORY PROFITS, OR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES.

The material in this manual is for informational purposes only. The products it describes are subject to change without prior notice, due to the manufacturer's continuous development program.

Questions or Feedback?

If you have any questions or if there is anything we can do to improve your experience, please let us know. We'd be happy to hear your feedback.

Trueform Concrete, LLC

105 W. Dewey Ave, Suite 509. Wharton NJ 07885 888.474.7977 info@trueformconcrete.com www.trueformconcrete.com